



# Cisco 1805 DOCSIS 2.0 Cable Router Quick Start Guide

---

This document lists where you can find detailed documentation for further installation, configuration and initial steps for connecting the Cisco 1805 Data-over-Cable Service Interface Specifications (DOCSIS) 2.0 Cable Router.

## Contents

- Registration and Documentation
- Connect the Router

## Registration and Documentation

To download and complete your product registration, access this URL:

<http://www.cisco.com/univercd/home/home.htm>

To access the Cisco 1805 DOCSIS 2.0 cable router product documentation, access this URL:

[http://www.cisco.com/en/US/products/ps5853/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/ps5853/tsd_products_support_series_home.html)

You can access other current Cisco documentation at this URL:

<http://www.cisco.com/univercd/home/home.htm>



---

**Americas Headquarters:**  
**Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA**


© 2007 Cisco Systems, Inc. All rights reserved.

# Connect the Router

To set-up and connect your router, follow these steps:

**Step 1** Verify that the following items were shipped with your router:

<b>1</b>	Ethernet cables	<b>3</b>	Cable adapter
<b>2</b>	Console cable	<b>4</b>	AC power cord



- Step 2** To connect up to four PC to the router, connect the Ethernet cable from the Ethernet switch ports to the PC.
- Step 3** To configure the router through the Cisco IOS command-line interface (CLI), connect the router console port to a terminal or PC.
- Step 4** To connect to an ISP, attach one end of the cable adapter to the Cisco cable modem HWIC (high-speed WAN interface card) and the other to the cable source.
- Step 5** Connect the power cord as shown. Move the power switch to the ON position.

The following indications appear:

- The green SYS PWR LED on the front of the chassis lights up.
- The fan operates.

**Step 6** Log on to your router through the console port and use the CLI to configure your router.

For detailed information about how to install and configure your router, see the following documentation:

- *Regulatory Compliance and Safety Information for Cisco 1840 Routers*
- *Cisco 1805 DOCSIS 2.0 Cable Router Hardware Installation Guide*
- *Cisco 1800 Series Software Configuration Guide*
- Cisco IOS software documentation, all releases

CCVP, the Cisco logo, and Welcome to the Human Network are trademarks of Cisco Systems, Inc.; Changing the Way We Work, Live, Play, and Learn is a service mark of Cisco Systems, Inc.; and Access Registrar, Aironet, Catalyst, CCDA, CCDP, CCIE, CCIP, CCNA, CCNP, CCSP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Cisco Unity, Enterprise/Solver, EtherChannel, EtherFast, EtherSwitch, Fast Step, Follow Me Browsing, FormShare, GigaDrive, HomeLink, Internet Quotient, IOS, iPhone, IP/TV, iQ Expertise, the iQ logo, iQ Net Readiness Scorecard, iQuick Study, LightStream, Linksys, MeetingPlace, MGX, Networkers, Networking Academy, Network Registrar, PIX, ProConnect, ScriptShare, SMARTnet, StackWise, The Fastest Way to Increase Your Internet Quotient, and TransPath are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries.

All other trademarks mentioned in this document or Website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0711R)

Any Internet Protocol (IP) addresses used in this document are not intended to be actual addresses. Any examples, command display output, and figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses in illustrative content is unintentional and coincidental.

© 2007 Cisco Systems, Inc. All rights reserved.

♻️ Printed in the USA on recycled paper containing 10% postconsumer waste.

